



USER MANUAL

NARROW SMART DOOR LOCK

OZ-FDL-33 LIFE SLN STD 



Fingerprint



User Password



OzoLife Mobile
App



RFID Card



Emergency Key



OzoLife



DOWNLOAD NOW



OzoLife iOS



OzoLife Android

WWW.OZONESECUTECH.COM

EMAIL ID: INFO@OZONESECUTECH.COM | CUSTOMER CARE: +91-9310012300

INDEX

Introduction	1-2
Lock Structure	3
Technical Specification	4
Installation Steps	5
Operation Steps	6-9
FAQ	10
Warranty Card	11

INTRODUCTION

CAUTION

- Necessary safety measures must be ensured before starting the installation to prevent damage to assets and personnel.
- Accuracy of the door preparation is a critical parameter for the proper door installation, Lock functioning, and security of the product.
- Any deviation from the given specs and misalignments etc., can cause performance and security breaches.
- The product images shown in this document are for reference & representation purposes only & the actual product may differ from these.
- Check for leveling & alignment of doors before installation of the product.

The image contained in this manual is a reference used for description and instruction, and its types and colors may differ following the product model.

Safety cautions



Prohibited

Do not directly spray water when cleaning the product.

Water coming through into the product causes malfunction or abnormal operation.



Prohibited

Do not dismantle the product yourself. It may cause malfunction of product.

If you dismantle the product yourself, the product may not function as it should.



Caution

Do not place inflammable such as gas lighter near the product.

It may cause malfunction or abnormal operation.



Caution

Completely block holes on door after product installation.

There is a risk of intrusion through door holes.



Caution

Do not use the product at places exposed to water.

Since the product does not have water and dust proof structure, it may cause product malfunction due to short circuit.



Prohibited

Do not use the product in place with direct sunlight or high temperature.

It may cause malfunction or abnormal operation.



Prohibited

Do not install the product at place where water, snow or rain can come through.

It may cause malfunction or abnormal operation.



Prohibited

Do not impact on or alter the product.

It may cause malfunction or abnormal operation.



Caution

Replace all batteries with new one when changing batteries.

If old batteries are used with new ones, product life span cannot be guaranteed



Caution

Use alkaline battery only.

Using rechargeable battery may cause product malfunction.

Caution

Since the product is a keyless door lock, a part of the door lock may get damaged in case of malfunction. Therefore, the user needs to be familiar with the manual closing and opening of the device in an emergency.

1. Voltage: DC6V
2. Be cautious that reverse installation of batteries may cause liquid leakage or a burst.
3. When the battery is discharged, replace all batteries and DO NOT use used batteries with a new one.
4. Sensor operation temperature: 60°C (+10°C).

INTRODUCTION

CAUTION

Special Note Before Installation

- Necessary safety measures must be ensured before starting the installation to prevent damage to assets and personnel.
- Accuracy of the door preparation is a critical parameter for the proper door installation, Lock functioning, and security of the product.
- Any deviation from the given specs and misalignments etc., can cause performance and security breaches.
- The product images shown in this document are for reference & representation purposes only & the actual product may differ from these.
- Check for leveling & alignment of doors before installation of the product.

Do's

- Admin/Master should always be used by the primary owner of the house and can be activated or deactivated by him only.
- Always change the default factory password in the applicable models immediately after the installation is complete.
- Inserting batteries in the wrong direction or wrong polarity in the battery compartment may lead to fluid tears or ruptures, so always make sure you insert the batteries as per the correct polarity, which matches the product's polarity (+/-).
- Always keep the Master Passcode safe, and in the case of forgotten Master Passcode, please get in touch with our helpline number for further assistance.
- Always use a soft and dry cloth to clean the product.
- Replace all old batteries with a new ones when changing batteries. Using old batteries in combination with the new ones can cause the product to malfunction.
- Use Alkaline batteries only.
- Using rechargeable batteries may cause product malfunction.

Dont's


- Do not Dismantle the product by yourself. Always take the help of the certified service technician for dismantling the product as improper handling may cause damage to the product resulting in malfunctioning of it.
- Do not insert batteries with reversed polarities. Always check and ensure proper polarity of batteries in line with Product Polarity while inserting it into the product as any mismatch can result in liquid leakage or rupture.
- Do not install, disassemble or repair the product without the help of a certified service technician.
- Do not give excessive impact force on the product.
- Do not directly spray water when cleaning the product. Water coming through into the product causes malfunction or abnormal operation.
- Do not install the product in an area exposed to the external environment.
- Do not let dew condensation enter the product as it may cause product malfunction if a certain level of moisture enters into it, so make sure to remove any source of dew condensation through periodic ventilation or paper weather stripping.

User Instruction

- Please read all the safety & operating instructions before the product installation.
- To ensure continuous access security, change your PIN code regularly.
- Only use new batteries & beware of potential battery leakage, which may cause damage/malfunction to the product.
- Replace all batteries when prompted by the automatic low battery indication and do not re-use any of the batteries.
- Installation must be done by an Ozone service professional.
- Disassembly or attempted repair, rework or reverse engineering is prohibited without written consent & approval of Ozone except for the normal installation of the product by a designated service professional.
- Clean the product only with a dry microfiber cloth.
- Do not insert or press any of the buttons with Pin or sharp objects.
- This product has not been tested for external use. Avoid any contact with water.
- This product was designed for use in weather-protected outdoor and indoor areas and domestic application only.
- Do not expose the product to strong shocks or vibration.
- Keep the filled-out warranty certificate and invoice, as it is required for processing all warranty requests.
- The information in this user guide is subject to change without notice.

This product must be installed by an Ozone professional. In case of defects resulting from installation by other than an Ozone professional, the Product warranty will be void. Ozone reserves the right to charge on out-of-warranty products.

LOCK STRUCTURE








PRODUCT FEATURES

- 1) Micro USB emergency power supply: In case of emergency the products could be operated by USB through power bank.
- 2) Emergency key unlock: Use emergency key to unlock the door when battery is completely drained or in any emergency situation.
- 3) Fingerprint: Use registered fingerprint to open the lock.
- 4) Digital keypad/RFID card inculcation area: use registered password or RFID card to open the lock.
- 5) Battery cover: Open battery cover to change the battery.
- 6) Reset button: Use reset button for factory setting or initialization settings.
- 7) Privacy locking knob: While enable privacy locking no one can open the lock from outside except emergency key.
- 8) Smart freeze & Auto secure: More than 5 times wrong password in 5 minutes, the keypad will be locked for 90 sec. the lock will respond to any operation within the 90 second.
- 9) Anti-theft password: Enter the password as follows when opening the door: XXX password XXX. you can add some irrelevant digits before and after the password, and then press # to confirm. the actual password must be included.
- 10) Break-in Alarm: If someone tries to break the lock, it sends a notification to the connected smart phone through the OzoLife App.

TECHNICAL SPECIFICATION

Lock Material	Zinc Alloy, ABS
Color	Black
Door Thickness	35-80mm
Communication	OzoLife
Support OS	iOS 7.0 or above, Android 4.4 or above
Battery Life	(6-8 months) by 15 times normal unlock
Power Supply	DC6V:4pcs AAA alkaline batteries
Static Current	≤ 50 uA
Dynamic Current	< 200 mA
Unlock Way	Fingerprint, RFID card, password Ozolife App, Emergency key
Unlock Time	1-1.5 Seconds
Working Temperature	-20° - 50°
Working Humidity	10% - 95%
Factory Passcode	Factory Master Password : 123456 after configuration, it will be invalid
Mortise Type	28*85mm
Virtual Password	Available
Administrator Capacity	9
User Capacity	FP+PWD+RFID card (300)
Door Application	Wooden/ Metal Door

INSTALLATION STEPS




OPERATION STEPS

Please enroll the master password/card/fingerprint before you start to use this lock. you can follow the operation steps as below:

1.Initialization


1

Press the reset button and hold 5 seconds



2


Long beep with: "Successful"



2.Enroll Master Password


1

Press * and # button by sequence




2

Input Administrator Information.




3

Enter default Master password:123456



4

Press 1 for administrator setting
Press 2 for user setting
Press 3 for system setting
Press 4 for reboot system



Press 1

5

Press 1 to add administrator setting
Press 2 to delete administrator
Press 3 network setting



Press 1

6

Input Administrator information



Enter 6-12 digits new password
Press # to confirm

7


Please enter again



Enter same password
Press # to confirm

8

00x,Successful!
input unlock information...




You can continue the operation
to add master card or password

⚠ Notice: the administrator can be password/ fingerprint or IC card,you can set according to your own requirement, total 9 administrators.


⚠ Notice: Press # key to confirm, press * to back to previous step, lock will exit the setting if there is no operation during 10 seconds.

⚠ Notice: After 5 times wrong unlock,the keypad will be locked for 30 seconds,there is no reaction for any operation during these time.


3.Delete Master Password




4.Enroll User Password




5.Delete User Password




6.Enroll User Card



7.Delete User Card



8.Enroll User Fingerprint






9.Delete User Fingerprint

- 1** Press * and # button by sequence

- 2** Input Administrator information.

- 3** Enter Master password
Such as:654321

- 4** Press 1 for admin setting
Press 2 for user setting
Press 3 for system setting
Press 4 for reboot system
 Press 2
- 5** Press 1 to add user
Press 2 to delete user.
 Press 2
- 6** Press 1 to delete number
Press 2 to delete all
 Press 1
- 7** Please enter number
confirm by # key


You can enter the number
like 010 to delete the user
- OR
 Press 2


10.System Setting

- 1** Press * and # button by sequence

- 2** Input Administrator information.


- 3** Enter Master password
Such as:654321

- 4** Press 1 for admin setting
Press 2 for user setting
Press 3 for system setting
Press 4 for reboot setting
 Press 3
- 5** Press 1 for voice setting
Press 2 for mode setting
Press 3 for language setting
Press 4 for time setting
Press 5 for changing room No.

- 6** Press 1:
You can disable or enable the
sound tip.
Press 2:
You can choose single mode
unlock or combination unlock.
Press 3:
Choose English
Press 4: Change lock time
Press 5: Change room No.


You can make the settings following the sound tip for the unlock type/Language/Lock time/Lock Number etc, these functions are designed for some special conditions.

11.Reset Setting




Notice: Above are the standard operation for the lock with password and keycard function.

9 APP SETTING

- 9.1) Add administrator (skip this operation if you have done this)
- 9.2) Search "OzoLife" in the APP store or other APP market to download it.
- 9.3) Register by mobile phone number then log in.
- 9.4) Find in OzoLife App the "Digital lock" and press "door lock (Wi-Fi)" and follow the instruction to finish adding lock.
- 9.5) Net connecting
- 9.6) Entering Wi-Fi setting menu
 - Press "*"#" to verify the administrator information.
 - Press 1 to enter administrator setting menu
 - Press 3 to finish the Wi-Fi setting.
- 9.7) Voice reports press 1 for hotspot connection (screen indicator light flashes slowly); press 2 for intelligent connection (screen indicator light flashes rapidly). Intelligent connection is recommended.
 - Hotpot connection operation
 - Enter Wi-Fi connection menu then press 1 to choose hotspot connection.
 - Choose the Wi-Fi hotspot to be connected to then input the right password.
 - Press "Next" then it will inform you "successful". If it failed, it will report "failed". Please try again the operation.
 - Intelligent connection operation
 - Enter Wi-Fi connection menu then press 2 to choose intelligent connection.
 - Choose the Wi-Fi to be connected to then input the right password.
 - Press "Next" then it will inform you "successful". If it failed, it will report "failed". Please try again the operation.
- 9.8) Keypad screen number 1234 will flash successively with voice "successful" when finish adding operation; if ?me out, voice will report "fail".
- 9.9) Remote unlock: wake the keypad and press "9#" then voice will report "requesting remote unlocking". Door lock ?me will be corrected while requesting remote unlocking.


OPERATION STEPS

Search OzoLife app from the App store and register Press *# after add admin then Then press 1 form add user. Open OzoLife App and access it and follow below way to add lock (Auto connection/add manually)




TEMPORARY CODE SETTING


- ❶ After adding temporary code, need to try on lock then finished.
- ❷ Max. Support 10 groups of code, and code can be edited or deleted.
- ❸ Temporary codes can be set by period.



- 4 Dynamic code: Can get from the dynamic code page. it is valid only for 5 min. or one time use only



- 5 Remote unlocking: Press 9 and “#” button. Unlock request coming on OZOlife app then unlock the door.



10. Packing Details

Name	QTY	Name	QTY
Front Panel	1pc	Rear Panel	1Set
Gasket Rub ber Plate	2pcs	Emergency Key	2Pcs
M4X45 screws	2pcs	User manual	1Pc
Cut out template	1pc	Mortise	1Pc
Spindle	1pc	Strike Plate & box	1Pc
4X20 screws	6pcs	Screw Ø6x35	3Pcs
RFID Card	2pcs	Battery Optional	4AAA Pcs
M4x35 screws	2pcs	Plate Case	1Pc

FAQ'S

1 How to read operation records?

Select "Opening record" option on lock main interface

2 After installation, touch sensing keyboard or screen not responding.

- a) First check that the positive and negative electrodes of the battery have been installed upside down.
 - b) Check whether the battery has enough power.
 - c) Remove the back panel body and see if it's connected with the front panel.
 - d) Remove the lock and check whether the connecting wires of lock body are not squeezed or twisted.
-

3 Unable to register fingerprint.

- a) Check the fingers for dirt or wear. Also check the fingerprint sensor on the lock for dirt and oil stains, etc.
 - b) Check if the fingerprint sensor is working properly (Press any fingerprint on sensor to see if there is any response).
-

4 Why is the smart lock consuming power faster than usual?

- a) Large standby power consumption.
 - b) Short circuit.
-

5 After how many incorrect password attempts will the lock go in auto secure mode? For how long it will be in auto secure mode?

Every time you enter a wrong password more than 5 times in a row, the keyboard is locked for 90 seconds.

WARRANTY CARD



CUSTOMER'S DETAILS			
Name		Address	
Mobile No.			
E-Mail ID			
City		Landmark	
State		Pin Code	

PRODUCT PURCHASE DETAIL				
Digital Door Lock			Dealer Name & Address	
Model No.				
Online / Offline			Installation Address	
Serial No.				
			Invoice No.	
			Total Quantity	

Serial No.	Floor No.	Flat No.	Warranty No.	Remarks

Customer Signature:

Technician Signature:

Date:

This image shows a full page of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page, typical of notebook paper. There are no margins, text, or other markings on the page.

Special Instructions:

- Carefully read this manual before installation and keep it in a safe place for future reference.
- If you have any doubts or disputes regarding the information in this manual, you can call our company for clarification.
- There may be some differences between the descriptions provided here and the actual devices, as our products are constantly developing and upgrading. We apologize if this manual does not contain all of the latest updates.